

# Drywall Contractor Photo Checklist

Drywall work — board hanging, taping, mudding, and finishing — covers up nearly every other trade on the job. Once paint goes on, board thickness, fastener patterns, tape bedding, and corner bead installation are impossible to verify. When a GC disputes scope, a homeowner claims cracking was caused by your work, or a finish coat fails inspection, the question is always the same: **can you prove the framing was inspection-ready, the board was hung correctly, and each coat was applied to spec?** This guide gives your crew the exact shots.

## THE 7 PHASES

### Document Every Phase, Protect Every Job

#### 01 PHASE Pre-Hang Site Assessment

- Framing inspection approval on-site
- Framing plumb & straight — documented
- All blocking in place before hang
- Mechanical rough-in complete — confirmed
- Insulation installed (where required)
- Fire blocking at penetrations verified
- Moisture or mold issues noted pre-work
- Permit & approved scope on-site
- Homeowner pre-existing conditions noted

#### 02 PHASE Board Delivery & Layout

- Board brand, type & thickness labeled
- Moisture-resistant board in wet areas
- Type X board in fire-rated assemblies
- Board quantity & delivery condition
- Layout plan — direction & stagger
- Ceiling board hung first — wide shot
- Board lifts or jacks in use
- Attic or crawlspace access maintained
- Special board (abuse-resistant) noted

#### 03 PHASE Hanging — Ceilings

- Ceiling board perpendicular to joists
- Screw spacing — field & edge documented
- Screws set — not over-driven or popped
- Butt joints staggered — no stacking
- End joints land on framing members
- Adhesive applied (if used)
- Blocking at all unsupported edges
- Recessed light / vent box cutouts clean
- Ceiling hang complete — wide shot



## 04 PHASE Hanging — Walls

- Board hung horizontally or vertically noted
- Screw spacing — field & edge documented
- No floating vertical joints at corners
- Cutouts for outlets & switches clean
- Corner bead type — metal or vinyl
- Control joint locations per spec
- Door & window jamb depth confirmed
- Moisture board at all wet wall locations
- Wall hang complete — wide shot per room

## 05 PHASE Taping & Mud Coats

- Paper tape embedded — no bubbles
- Mesh tape (where used) — type & location
- Compound type — setting or drying noted
- First coat — butt joints & fasteners
- Second coat — feathered & widened
- Finish coat — skim or level 5 noted
- Texture — type & pattern documented
- Corner bead — straightness confirmed
- All coats — progression photos per room

## 06 PHASE Finishing & Level of Finish

- Level of finish (L1–L5) specified & confirmed
- Level 4 — smooth, paint-ready documented
- Level 5 — skim coat fully applied
- Sanding — grit & method documented
- No tool marks, ridges, or trowel lines
- Corner bead plumb & tight to board
- Reveals at windows & doors consistent
- Touch-up mud & sand — before & after
- Final finish — wide shot per room

## 07 PHASE Final Inspection & Closeout

- Permit card & inspection sticker
- Inspector approval documented
- All fasteners dimpled — none popped
- No cracks at butt joints
- Fire-rated assembly details confirmed
- Cleanup complete — no debris
- GC or owner walkthrough documented
- Punch list — before & after photos
- As-built notes on deviations from plan

HOW TO USE THIS IN THE FIELD

## Turn This Checklist Into Your Daily Workflow

- 01 Photograph the Framing Before Hanging Any Board**

Framing plumb, blocking, and rough-in completion are all invisible once board goes up. These shots prove the substrate was correct — protecting you from callback disputes caused by framing or mechanical issues that were never your responsibility.
- 02 Capture Screw Patterns Before Tape & Mud Cover Them**

Field and edge screw spacing, dimple depth, and butt joint placement disappear under the first coat of mud. A close-up shot of each wall and ceiling proves your fastening was correct.
- 03 Document Each Coat Progression in Every Room**

A photo of each coat — first, second, and finish — in every room creates a time-stamped record of your process. This is your defense against claims that coats were skipped or rushed.
- 04 Wide Shot Before and After Every Room**

A before-hang and after-finish pair for each room documents your complete scope and shows exactly what you delivered — the clearest possible evidence in any GC or homeowner dispute.

## Start Documenting Like a Pro With a 7-Day Free Trial of Pixly.ai

Give your crew the photo documentation system built for drywall contractors.

**Only \$24.99 / month after your free trial.**

**TRY PIXLY FOR FREE**

Download on the App Store | ANDROID APP ON Google play



VISIT OR BOOK A DEMO





<https://pixly.ai>

Scan to download on App Store or Google Play · visit [pixly.ai](https://pixly.ai)



## THE EASIER CONSTRUCTION PHOTO APP.

The Easiest Way To Prove Your Work,  
Track Projects or Tasks & Get Job Photos  
Off Your Phone & Drives.  
Users Save 1+ Hour a day.



### TRY PIXLY FOR FREE



VISIT OR BOOK A DEMO



<https://pixly.ai>



#### STOP SKETCHY DISPUTES

Time stamped, location stamped records of pre-construction conditions, progress and work completed.



#### STOP WORK PHOTO CHAOS

Never text another work photo. Never upload to another disorganized drive. Never lose photos in between family pictures.



#### ASSIGN AND TRACK TASKS

Snap, Tag, Share & Collaborate. Get a list of open items and close them out in real time. Send instant end of day reports.



#### SIMPLE & AFFORDABLE

Pixly was created for the field. Get Started in 10 minutes with little to no training. Only the features contractors need. No Fluff.

Start Documenting Like a Pro With a 7-Day Free Trial of Pixly.ai

Only \$24.99 / month after your free trial · [pixly.ai](https://pixly.ai)

Available on App Store & Google Play

